OKI®

B4350
B4350n

Software Installation Guide

59362601

Oki, Network Solutions for a Global Society

Before Installing the Software

To print from the computer and use all of your printer's features, you must install the printer drivers. Before using your printer, follow these instructions to install the drivers.

The drivers are located on the CD-ROM included with your printer.

Installation instructions are included for printers connected to computers by a USB connection and a parallel connection.

NOTE

Oki Data recommends using a USB connection, as your printer is performance optimized for a USB interface.

NOTE

For more information about your printer, install the User's Guide located on the CD-ROM.

CONTENTS

Local Printer Installation: Windows 4

Network Printer Installation: Windows 6

Macintosh® OS 9.1+ Installation 7

Macintosh® OS X.1+ Installation 8

If you need further assistance or have questions

- See our web site: http://my.okidata.com
- In the U.S. and Canada, Call: 1-800-OKI-DATA (1-800-654-3282) 24 hours a day, 7 days a week

README FILE

For the latest printer driver information, see the Readme file on the CD supplied with your printer.

Local Printer Installation: Windows®

INSTALL THE PRINTER DRIVER

NOTE

The installation procedure may vary slightly depending on the operating system and interface connection you are using. Drivers are provided for Windows® XP, 2K, Me, and 98

1. Make sure the cable is connected to your printer and PC and your printer is turned **OFF**.
2. Insert the driver CD supplied with your printer into your CD-ROM drive. The CD will autorun. (If it doesn't, click **Start** → **Run** → **Browse**. Browse to your CD-ROM drive and double-click **Install.exe**, click **OK**.)
3. The License Agreement appears**.** Click **Next** if you accept the terms.
4. Select your language.
5. Select the printer model. Click **Continue**.
6. The Software Installation screen appears. Click the **Printer Driver Installer** button.
7. Click **Local printer**. Click **Next**.
8. Select the port (**USB** or **LPT1** parallel). Click **Next**.
9. Printer model displays. Click **Next**.
10. If prompted, type a printer name for your printer. Click **Next**.
11. If prompted, select "do not share this printer" Click **Next**.
12. Drivers are copied. **Connect cable** message may appear.
13. Switch the printer **ON**.

NOTE

If New Hardware Found Wizard displays:

Win 98*: Select "Search for the best driver for your device". Click* ***Next****. Select CD-ROM drive, clear other choices. Click* ***Next*** *twice.*

Win XP and Win Me*: Select "Automatic Search for a better driver." Click Next.*

14. Click **Finish** to complete the installation.
15. If Connect cable screen is open, click **Finish** to close it.

Local Printer Installation: Windows® (cont'd)

INSTALL THE ON-LINE USER'S GUIDE

NOTE

In order to open the on-line User's Guide, you must have Acrobat Reader installed.

1. Click the **Documentation** button.
2. Click the **Install User's Guide** button.
3. Follow the on-screen instructions.

Print a Test Page

1. Click **Start →Settings→Printers.**
2. Right-click **OKI B4350(PCL)** icon.
3. Click **Properties**.
4. Click the **General Tab**.
5. Click the **Print Test Page** button.

Network Printer Installation: Windows

INSTALL THE PRINTER DRIVER

NOTE

The B4350n printer is network-ready. To network the B4350 printer, the optional OkiLAN 8100e Internal Printer Server (PN 70049701), or 6020e External Print Server (PN 70036001) must be installed.

NOTE

For additional information, install the Network User's Guide located on the CD-ROM. Run the Menu Installer, then click the Documentation/Network User's Guide buttons.

Before beginning the installation:

- If you are not using DHCP, you need to obtain an IP Address from your network Administrator and enter it using the front panel:
- Press Menu until you see **NETWORK** on the display, then press SELECT.
- Press ITEM until you see **IP ADDR.** on the display, then press SELECT.
- Press VALUE to change the setting to **MANUAL**, and press SELECT.
- Press ITEM+ to advance to the **IP ADDRESS** display, then press SELECT.
- Use the VALUE+ and – to set each set of three digits in the IP Address.
- Press SELECT to engage the IP Address, then press ON LINE.

Driver Installation:

1. Insert the CD into your CD-ROM drive. The CD will auto-run. (If it doesn't, click **Start→Run→Browse**. Browse to your CD-ROM drive and double-click **Install.exe**, click **OK**.)
2. The License Agreement appears. Click **Next** if you agree.
3. Select the language.
4. Select the printer model. Click **Continue**.
5. Click the **Printer Driver Installer** button.
6. Select **Network Printer**. Click **Next**.
7. Shared printer type displays. Follow the on-screen instructions to complete the installation.

For additional information, see the OkiLAN 8100e Network User's Guide located on the CD.

NOTE

In order to send documents to the printer, the LPR utility must be installed. This utility installs automatically when the drivers are installed from the Installation CD using the Menu Installer as instructed here. If drivers are installed using Windows Add Printer Wizard, you need to load the LPR Utility from the Menu Installer —click the Network Install button, click Installation/Config/OKI LPR.

Macintosh® OS 9.1+ Installation

INSTALL THE DRIVER

1. Turn on the printer, then turn on the computer.
2. Place the Drivers CD supplied with your printer into the CD-ROM drive.
3. Double-click the CD icon that appears on the desktop.
4. Open the MAC folder.
5. Double-click the PCLDRV folder.
6. Open your language folder.
7. Double-click the **OKI B4350 MAC Installer** icon, then click **Continue** and accept the license agreement.
8. Select **MAC OS 9.1+Install** from the drop-down menu. Click I**nstall**.
9. When the installation is complete, click **Quit**.

Create the Desktop printer for USB

1. Activate Chooser from the Apple menu.
2. Select the **B4350 USB** icon.
3. Highlight the printer model.
4. Close Chooser.

ON-LINE MANUALS

To Load the Manuals

Note: *In order to open the on-line manual, you must have* Adobe® Acrobat® Reader *installed.*

1. Insert the Installation CD into your CD-ROM drive.
2. From the **CD contents** folder, either open the file directly or drag the **Manual** folder to copy them to the desktop.

Macintosh® OS X.1+ Installation

INSTALL THE DRIVER

NOTE

Be sure to switch off antivirus software before installing a printer driver.

1. Turn on the printer, then turn on the computer.
2. Place the Drivers CD supplied with the printer in the CD-ROM drive.
3. Double-click the CD icon that appears on the desktop.
4. Open the MAC folder.
5. Double-click your language.
6. Double-click the **OKI B4350 Mac Installer** icon, then click **Continue** and accept the License agreement.
7. Select **Custom Install** from the drop-down menu located in the left corner. Click **Install**.
8. Check **PCL Driver for MAC OS X.1+**. Click **Install**.
9. When the installation is complete, click **Quit**.

ADDING THE PRINTER FOR USB

1. Run the Print Center (**Local HD** → **Applications** → **Utilities** → **Print Center**).
2. Click **Printers** from the menu bar.
3. Click **Add Printer**.
4. Select **OKI USB** from the drop down menu.
5. Highlight the printer model from the product list.
6. Click **Add**.
7. Close the Print Center.

ADDING THE PRINTER FOR A NETWORK

1. Run the Print Center (**Local HD** → **Applications** → **Utilities** → **Print Center**).
2. Click **Printers** from the menu bar.
3. Click **Add Printer**.
4. Select **OKI TCP/IP** from the drop down menu.
5. Enter the IP address.
6. Highlight the printer model from the product list.
7. Click **Add**.
8. Close the Print Center.

ON-LINE MANUALS

To Load the Manuals

Note: *In order to open the on-line manual, you must have* Adobe® Acrobat® Reader *installed.*

1. Insert the Installation CD into your CD-ROM drive.
2. From the **CD contents** folder, either open the file directly or drag the **Manual** folder to copy them to the desktop.

OKI is a registered trademark of Oki Electric Industry Company, Ltd.
Microsoft, Internet Explorer and Windows are either registered trademarks
or trademarks of Microsoft Corporation in the United States and other countries.
Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corporation.
Apple, Macintosh, Mac and Mac OS are registered trademarks of Apple Computer.
Other product names and brand names are registered trademarks or trademarks of their proprietors.

Oki Data Americas, Inc., 2000 Bishops Gate Blvd., Mt. Laurel, NJ 08054-4620
Tel: 1-800-654-3282 (856) 235-2600 Fax: (856) 222-5320, www.okidata.com

© 2004 Oki Data Americas, Inc.

59362601